BACKFILL REMOVAL BLADES

WK17-6 Backfill Removal Blade - Quickly Removes Old Urethane between Panel & Glass

Refer to page 17 for backfill removal option

WK17-4 Backfill Removal Blade - 4mm Blade Channel Width


WK26 Cutting Depth Control Arm



WK17 Blade + WK26 arm on the BTB Tool

 Excellent for Buses, R.V.'s, Trains & Marine


Edge (6mm Blade Channel Width) using WK5-S blade



WK16 Glass & Moulding Separation (Use Manually or in Power Tool)



WK16SL Short Tail Left Hand (5mm Tip) WK16SR Short Tail Right Hand (5mm Tip) WK16LL Long Tail Left Hand (8mm Tip) WK16LR Long Tail Right Hand (8mm Tip)



Slide WK16 between moulding and glass. Glass will slide down and out of moulding

سرWK16

TOOLKIT ACCESSORIES - (INCLUDED IN TOOLKITS)

Urethane in

divisional joint


WKGA Acessory Pack (included with WK10HD)



32 - Steel 24 - Universal (Supplied) 18 - Plastics IIIIISaw Blade

TEETH PER INCH

Urethane



WK7 Manual Blade Handle (Fits All Blades). Requires WKKEY Allen Key









WK7L Manual Blade Double Handle (Fits All Blades). Requires WKKEY Allen Key

WK8 Sharpening Stone (For Re-sharpening All Blades)




WK9

Lubricant Spray Bottle (Adjustable Spray Nozzle)



WK20 Plastic Paddle/Lever Tool - Clean Up, Won't Scratch Glass



WK11VEL

Velcro® Self Adhesive pads (Per Metre)

- Qty approx 25 adhesive tabs



WK12-CD

Promotional & Product Introduction CD-ROM -6 Languages x 9 minutes



WK12TCD

Auto Glass Removal Training CD-ROM -26 Minute Video Plus Additional Information



WK-BX Sturdy Plastic

Carry Box

(Contents not included)

